



Calisto® P830™ Quick Setup Guide

Welcome:

Using a Plantronics Calisto speakerphone for PC calls will deliver a simpler, more comfortable and better sounding audio experience than you could get using just your computer's internal microphone and speaker.



Calisto P830 Key Features:

- Seamlessly switches between calls from PC, mobile and home landline
- Color display and touch sensitive keys for intuitive visual call management
- Full duplex wideband audio support and advanced noise cancellation
- User friendly Caller ID and call log

Getting started:

Follow the steps below to get call answer/end controls with your Calisto speakerphone and **Cisco® Unified Communications Integration for Cisco WebEx Connect®**.



1. Connect your speakerphone to the computer. If this is the first time you are connecting, wait for the installation process to complete.
2. To get call control features, please download the latest version of Plantronics software at plantronics.com/software.

Note: Check with your IT staff before installing software on your computer.

Configuring Cisco Unified Communications Integration for Cisco WebEx Connect to always route call audio to the speakerphone:

3. Click **Edit** in the upper left corner of the Cisco WebEx Connect main screen.
4. Then select **Settings**.
5. Next choose **Audio/Video**.
6. Select your Plantronics speakerphone in the drop down for both Speakers and Microphone.
7. You can also adjust the Speakers and Microphone volume in this screen.
8. When you are finished, select **Save**.

Note: USB configuration settings are unique for each USB port. If you connect the speakerphone to a different port you will need to make these changes again to set behavior for that USB port.



Making and Receiving Calls with Cisco Unified Communications Integration for Cisco WebEx Connect

To MAKE a call:

To call an existing contact, select the Contact Tabs (1) and select the contact you would like to call. Right click on their picture (2), select Start Call (3) and choose a number (4).

You can also enter a phone number manually using the dial pad on the speakerphone or the search box located near the top of the Cisco WebEx Connect main screen (5).

When a call is placed, a call notification will appear in the Cisco WebEx Connect main screen, and the audio will be routed to your speakerphone.

To RECEIVE a call:

When you receive a call, a notification window will appear in the lower right corner of your computer screen (6).

To answer the call, use the controls on your speakerphone or click the green Answer button (7) in the call notification window.

