

# Quick User Guide



plantronics®

## Plantronics CS540

Wireless Headset System



Three convertible wearing styles



### 1 Volume/mute button

Increase volume	Press up*
Decrease volume	Press down*
Mute	Press in

\*NOTE If headset worn on left side, positions reversed.

### 2 Answer/end call button (tap)

### 3 Narrowband/wideband audio switch

Black	Narrowband Audio
Yellow	Wideband Audio (deskphone must be capable of wideband audio)

### 5 Auto answer switch

Black (off)	Tap call control button to place or answer call
Grey (on)	Lift headset from base to place or answer call

**NEED SUPPORT?**

800.641.6416 or  
CHAT ONLINE

 **unified**  
communications™  
.com