

Quick User Guide

plantronics®

Plantronics Savi W710/W720

Multi-Device Wireless Headset System


Savi W710 is monaural. Savi W720 is binaural.

Press top buttons on base to switch between devices. Green LED denotes active device.



Bluetooth pairing

Hold 4 seconds until LED flashes red and blue. Select "Savi 7xx" from Bluetooth device. If prompted, passcode is 0000. LED on base will turn solid blue once active connection is made.



1 Decrease volume/flash button

Decrease volume

Short press

Flash/Incoming call

While on call, long press (1.5 sec) up or down, will put call on hold and answer another

2 Answer/end call button

3 Mute button

4 Increase volume/flash button

Increase volume

Short press

Flash/Incoming call

While on call, long press (1.5 sec) up or down, will put call on hold and answer another

NEED SUPPORT?

800.641.6416 *or*
CHAT ONLINE

 **unified**
communications™
.com