

Quick User Guide

plantronics®

Plantronics Savi W740

Multi-Device Wireless Headset System




Three convertible wearing styles

Press top buttons to switch between devices.
Green LED denotes active device.



Bluetooth pairing

Hold 4 seconds until LED flashes red and blue. Select "Savi 7xx" from Bluetooth device. If prompted, passcode is 0000. LED on base will turn solid blue once active connection is made.



1 Volume/Mute/Flash Button

Press up or down to adjust volume
Press in to mute/unmute
During a call, press up or down for 1.5 sec to switch between calls

2 Call Control Button

Press to answer/end calls

3 Headset LED

Flashes white when in use

NEED SUPPORT?

800.641.6416 *or*
CHAT ONLINE

 **unified**
communications™
.com